

PIP VANGUARD G4 PAPR - DONNING & DOFFING GUIDE



VANGUARD G4

PRK-G4SR2P-1
VANGUARD G4
AIR PURIFYING RESPIRATOR PAPR COMPLETE KIT

BEFORE USE CHECKS

- >> Battery charged
- >> Filter, spark screen & pre-filter installed
- >> Hose connected
- >> Visor clean
- >> Airflow and alarm test passed

DONNING

1. Don the Blower and belt
2. Connect hose
3. Turn ON PAPR
4. Select airflow
5. Fit headtop and adjust seal
5. Check airflow before entry

DOFFING

1. Exit contaminated area
2. Remove headtop
3. Disconnect hose
4. Turn blower OFF
5. Remove belt assembly
5. Inspect equipment

CRITICAL SAFETY

**NEVER REMOVE THE HEADTOP, DISCONNECT THE HOSE, OR SWITCH OFF THE BLOWER
IN A CONTAMINATED AREA. LEAVE IMMEDIATELY IF AIRFLOW DROPS OR ALARMS ACTIVATE.**